

EasyPrep Virus DNA/RNA Kit

For simultaneous purification of viral RNA and DNA from plasma, serum, and cell-free body fluids

Contents

| Introduction | 2 |
|--------------|---|
| Kit Contents | 4 |
| Protocol | 4 |

Introduction

EasyPrep Virus DNA/RNA Kit provides a fast, simple, and cost-effective viral DNA/RNA miniprep method, and it is suitable for viral RNA and DNA from plasma, serum, and cell-free body fluids. This product uses silica membrane technology and thus avoids the cumbersome steps associated with loose resins or slurries. Viral DNA/RNA purified with the EasyPrep Virus DNA/RNA Kit is immediately ready for use. Phenol extraction and ethanol precipitation are not required. The purified DNA/RNA is ready for use in downstream applications such as enzymatic reactions, RT–PCR, and Southern blotting.

Important Note:

- 1. All protocol steps should be carried out at room temperature (15–25 °C).
- 2. Equilibrate the samples to room temperature.
- 3. RNase-free microcentrifuge tubes (1.5 mL) are used in step 13. Others are not supplied.

Preparation of Carrier RNA solutions

- 1. Buffer GBD is supplied as a concentrate. Before using for the first time, add 60 mL ethanol (96%–100%), to obtain a working solution.
- 2. Add 310 μ L of RNase-free ddH₂O to the tube containing 310 μ g of lyophilized carrier RNA to obtain a solution of 1 μ g/ μ L. Dissolve the carrier RNA thoroughly, divide it into conveniently sized aliquots, and store it at -20 °C. Do not freeze—thaw the aliquots of carrier RNA more than three times.
- 3. Carrier RNA cannot be dissolved in Buffer GBB directly. It must first be dissolved in RNase-free ddH₂O and then added to Buffer GBB.
- 4. Carrier RNA working solution: Calculate the volume of Buffer GBB/Carrier RNA mix required per batch of samples by selecting the number of samples to be simultaneously processed from Table 1.

Note: For larger numbers of samples, volumes can be calculated using the following sample calculation.

```
n \times 0.22 \text{ mL} = y \text{ mL}
```

 $y~mL \times 28~\mu L/mL = z~\mu L$

n = number of samples to be processed simultaneously

y = calculated volume of Buffer GBB

z = volume of carrier RNA/RNase-free ddH₂O to add to Buffer GBB

Table 1 Volumes of Buffer GBB and Carrier RNA/RNase-free ddH₂O Mix required for the Procedure

| No. Sample | Vol. Buffer GBB (mL) | Vol. Carrier RNA/ RNase-free ddH2O (μL) |
|------------|----------------------|---|
| 1 | 0.22 | 6.2 |
| 2 | 0.44 | 12.3 |
| 3 | 0.66 | 18.5 |
| 4 | 0.88 | 24.6 |
| 5 | 1.10 | 30.8 |
| 6 | 1.32 | 37.0 |
| 7 | 1.54 | 43.1 |
| 8 | 1.76 | 49.3 |
| 9 | 1.98 | 55.4 |
| 10 | 2.20 | 61.6 |
| 11 | 2.42 | 67.8 |
| 12 | 2.64 | 73.9 |
| 13 | 2.86 | 80.1 |
| 14 | 3.08 | 86.3 |
| 15 | 3.30 | 92.4 |
| 16 | 3.52 | 98.6 |
| 17 | 3.74 | 104.7 |
| 18 | 3.96 | 110.9 |
| 19 | 4.18 | 117.0 |
| 20 | 4.40 | 123.2 |
| 21 | 4.62 | 129.4 |
| 22 | 4.84 | 135.5 |
| 23 | 5.06 | 141.7 |
| 24 | 5.28 | 147.8 |

Note: Mix Buffer GBB with carrier RNA solution upside down. Do not vortex to avoid bubbling.

Kit Contents

| Contents | DPT-BC15 (50 preps) |
|--|---------------------|
| Buffer GBB | 15 mL |
| Buffer GBD | 13 mL |
| Buffer RBW | 15 mL |
| RNase-free ddH2O (Bottled) | 15 mL |
| Proteinase K | 1 mL |
| Carrier RNA | 310 μg |
| RNase-free ddH2O (Tubular) | 1 mL |
| RNase-free Spin Columns CR2 | 50 |
| RNase-free Microcentrifuge Tubes (1.5ml) | 50 |

Storage

- 1. All buffers should be stored at room temperature (15–25 $^{\circ}$ C).
- 2. Lyophilized carrier RNA can be stored at room temperature (15–25 °C) until the expiration date shown on the kit box. Carrier RNA should be dissolved in RNase-free ddH₂O and stored at -20 °C. Dissolved carrier RNA should be added to Buffer GBB as described. This solution should be prepared fresh and is stable at 2–8 °C for up to 48 h.

Protocol

- 1. Pipette 20 μL proteinase K into a clean 1.5-mL microcentrifuge tube (not provided).
- 2. Add 200 μ L of plasma or serum to the microcentrifuge tube (equilibrate the samples to room temperature.).

Note: If the sample volume is <200 μ L, add the appropriate volume of 0.9% sodium chloride solution to bring the volume of protease and sample to 220 μ L.

3. Add 200 μL of Buffer GBB (containing 28 $\mu g/mL$ Carrier RNA).

Close the cap and mix through pulse-vortexing for 15 sec.

Note: To ensure efficient lysis, it is essential that the sample and Buffer GBB are mixed thoroughly to yield a homogeneous solution..

- 4. Incubate at 56 °C for 15 min in a heating block. Briefly centrifuge the 1.5-mL tube to remove drops from the inside of the lid.
- 5. Add 250 μ L of ethanol (96%–100%) to the sample (precipitates may be visible after adding ethanol), close the cap, and mix thoroughly through pulse-vortexing for 15 sec. Incubate the lysate with ethanol for 5 min at room temperature (15–25 °C).

Note: Cool ethanol (96%–100%) on ice before use if the room temperature is >25 °C.

- 6. Briefly centrifuge the 1.5-mL microcentrifuge tube to remove drops from the inside of the lid.
- 7. Carefully transfer the lysate, including any precipitate that may have formed, onto the RNase-free Spin Columns CR2 in a 2-mL RNase-free Collection Tube without wetting the rim. Close the cap and centrifuge at 8,000 rpm (~6,000 ×g) for 1 min. Discard the filtrate; place the spin column in the same Collection Tube.

Note: If the lysate has not completely passed through RNase-free Spin Column CR2 after centrifugation, centrifuge again at higher speed until the spin column is empty.

- 8. Carefully open RNase-free Spin Column CR2, and add 500 μ L of Buffer GBD (Ensure that ethanol (96%–100%) has been added into Buffer GBD before use) without wetting the rim. Close the cap and centrifuge at 8,000 rpm (\sim 6,000 \times g) for 1 min. Discard the filtrate and place the spin column in the same Collection Tube.
- 9. Carefully open the RNase-free Spin Columns CR2, and add 600 μL of Buffer RBW (Ensure that ethanol (96%–100%) has been added into Buffer RBW before use) without wetting the rim. Close the cap, let it stand still for 2 min, and centrifuge at 8,000 rpm (~6,000 ×g) for 1 min. Discard the filtrate, and place the spin column in the same Collection Tube.
- 10. Repeat step 9.
- 11. Carefully open the RNase-free Spin Column CR2 and add 500 μ L of ethanol (96%–100%) without wetting the rim. Close the cap and centrifuge at 8,000 rpm (~6,000 ×g) for 1 min. Discard the filtrate.

Note: Ethanol carries over into the elute may cause problems in downstream applications.

- 12. Place RNase-free Spin Column CR2 in the same Collection Tube. Centrifuge at full speed 12,000 rpm (~13,400 ×g) for 3 min to dry the membrane completely.
- 13. Place RNase-free Spin Columns CR2 in a clean 1.5-mL RNase-free microcentrifuge tube, and discard the Collection Tube with the filtrate. Carefully open the lid of the spin column, and apply $20-150~\mu L$ of RNase-free ddH₂O to the center of the membrane. Close the lid, and incubate at room temperature (15–25 °C) for 5 min. Centrifuge at full speed (12,000 rpm; ~13,400 ×g) for 1 min.

Note: Ensure that the elution buffer is equilibrated to room temperature (15–25 $^{\circ}$ C). If elution is performed in small volumes (<50 μ L), the elution buffer must be dispensed onto the center of the membrane for complete elution of bound RNA and DNA.

BIOTOOLS CO., LTD

www.tools-biotech.com +886-2-2697-2697 info@tools-biotech.com